

## FRAME HARDWARE

### Torque Specs

#### Ripley

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Clevis to Swingarm Bolts	5 Nm	Loctite 243
Eccentric Shaft Bolts	4 Nm	Titanium Bolts: use ti anti-seize on the shaft and Loctite 243 on the threads Aluminum Bolts: use grease on the shaft and Loctite 243 on the threads
Lower Shock to Clevis Bolts	8 Nm	Loctite 243
Upper and Lower Eccentric Core Bolts	8 Nm	Loctite 243
Upper Shock Mount Bolts	4 Nm	Ti anti-seize

#### HD3

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Cable Port	2 Nm	Grease
Clevis to Seatstay	15 Nm	Loctite 243
Front Derailleur Cover Mount	5 Nm	Loctite 243
Front Derailleur Mount	5 Nm	Loctite 243
Lower Links	15 Nm	Loctite 243
Lower Shock to Clevis Bolts	15 Nm	Loctite 243
Rear Brake Caliper	6 Nm	Loctite 243
Seat Binder	5 Nm	Ti anti-seize
Upper Link Bolts	10 Nm	Loctite 243
Upper Shock Mount Bolts	4 Nm	Ti anti-seize

#### Mojo HD and HDR

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Front Derailleur Bolt (Direct Mount)	5-7 Nm	Grease
Forward Shock Mount Bolts	6 Nm	Loctite 243
Lower Link Bolts (Both)	10 Nm	Loctite 243
Non QR Seat Binder Bolts	5 Nm	Grease
Rear Brake Caliper Bolts	6 Nm	Loctite 243
Rear Shock Bolt	6 Nm	Grease for a stainless steel bolt and ti anti-seize for a titanium bolt
Upper Link Bolts	6 Nm	Loctite 243 for a steel pin and ti anti-seize for a titanium bolt

#### Tranny 29

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Cable Port	2 Nm	Grease
Seat Stay Bolts	10 Nm	Ti anti-seize
Slot Machine Bolt (Geared Riding)	25-30Nm	Ti anti-seize
Slot Machine Bolt (Single Speed Riding)	25-30Nm	Ti anti-seize

#### All Models

HARDWARE	TORQUE SPEC.	THREAD TREATMENT
Derailleur Hanger Bolt	5 Nm	Grease

